

INSTALLATION *(Straight Rail)*

Tools needed: tape measure, miter saw or hacksaw, drill and a level.

Before you begin installation, please check with your local building code official for required rail height in your area. To get started, unpack contents of box and locate top rail, balusters, brackets, and a pack of screws for the "T" Rail.



1 Measure the opening and mark distance on top and bottom rails. Make sure you have the same distance to the first hole on each end to assure a uniform appearance.



2 Trim excess off each end and insert peg into bottom rail.
Formula for peg length: desired clearance from bottom rail to deck + 3" = length of peg.



3 Place one mounting bracket and bracket cover on each end of top and bottom rail. Place bottom rail into opening, level and secure with four screws.



4 Insert balusters into routed holes. Holding top rail at an angle, connect top rail to balusters one baluster at a time.



5 Level vertically and secure top rail with screws.



6 Level balusters side to side and place two leveling screws through top and bottom brackets. Slide cover over bracket mount.